

A time and cost effective method of precisely levelling new sub floors or existing uneven floors.

OVERVIEW

TEKCEM SCREED LEVELLING PINS are a simple yet ingenious tool used to ensure that a floor is laid to exactly the correct desired level.

Traditionally, the levelling of floors has been done via laborious methods - e.g. drilling, plugging and screwing mounting screws into the floor – or even worse: by rule of thumb!

The TEKCEM SCREED LEVELLING PIN method of levelling provides increased accuracy at a significant cost saving.

TECHNICAL DATA

Packaging	100 pins per pack
Appearance	Plastic

BENEFITS

- Lightweight, portable.
- Easy-to-read millimetre and inch scale.
- Easy to cut using scissors or sharp blade.
- Bright colour makes them easily visible.
- Heavy duty adhesive backing reduces risk of movement.
- Covering paper easily detaches from self-adhesive tape.

METHOD

- Apply TEKPRIME primer as per manufacturers instruction.
- Carefully measure and mark the floor.
- Cut the levelling pin to the desired height, using the moulded millimetre or inch rule along the pin as a guide.
- Peel off the self adhesive backing from the base of the pin and adhere the pin to the floor, applying firm even pressure.
- Apply the concrete or screed until it just about covers the top of the pin.
- Lightly trowel flat to finish.



Updated: 08/06/2019

SETTING NEW LEVELS
 The Screed Development Centre
 Unit 1 Power Park, Commercial Road
 Goldthorpe Industrial Estate
 Rotherham, S63 9BL

Full installation guide can be found on our website:

WWW.TEKCEM.CO.UK
WWW.TEKFLOOR.CO.UK
 Sales: 01709 261 007
 Technical: 03300 553 714